

## Setup Instructions for the iOS / Android Endoscope

1. Make sure the battery box (black) is **fully charged**.
2. Download **Wi-Fi View** from the **App Store (iPhone) or Play Store (Android)**.
3. Once it's charged; plug the cable into the Wi-Fi connector on black box. Turn on the power (Figure 1).
4. Go to **Settings** on the iPhone / Android > **Wi-Fi** > It should provide you a **list of available Wi-Fi connection**. Typically, it will start with "**jetxxxxxxx**"
  - a. Select the one that doesn't look familiar. The password is: **12345678**
5. Once that is completed; the endoscope should work.



Figure 1.